

- MURATA VIJAYLAXMI TFO**



364-121-001 TENSION PULLEY CPL. ASSY



363-141-060 SHAFT



364-141-061-CHANGE-GEAR-BOSS



364-160-001 OIL CASE ASSY



364-240-006 DRUM



364-240-006 & 010 DRUM WITH APRON



364-240-009 COUPLING



364-250-001-&-002-YARN-GUIDE-&-LEVER



364-250-009 METAL



364-270-014-FEED-ROLL-CPL-CERAMIC-&-FEED-ROLLER-CPL.



364-300-004 GUIDE ROLLER CPL WITH HOOK & RADIAL BALL BEARING



360-312-016 HOLDER



364-310A-001 CHEESE COVER CPL



364-310A-SPINDLE-CPL.



364-310C- SPINDLE CPL
160 DIA MODEL 363-||
AIR THRADING



364-310C- SPINDLE CPL
180 DIA MODEL 373-||
AIR THRADING



364-310A-017 GUIDE



364-310C-005 GUIDE



364-330-003-&-004X-
GUIDE-WIRE-WITH-
YARN-GUIDE



364-330-006 & 009
BOSS & SCREW



364-340--COUPLING-
CPL



364-341-005 HOLDER



364-341-007 HOLDER1



364-341-018-DROP-
WIRE



364-350-001X-BRAKE-ROLLER-CPL



364-350-012 KNEE LEVER BRACKET



364-350-013-LEVER



364-350-31 BRAKE ARM CPL



364-500-011 CRADLE CAM



364-520-005-BUNCH-ROLLER-BRACKET-CPL.



364-600A TENSOR CPL WITH FLYER ASSY



364-600B-001-TENSOR-CPL.-FOR-AIR-THREADING



364-600A-17,-18-UPPER-CAPSULE-&-LOWER-CAPSULE



364-600A-035 FLYER



364-610-001-&-003-POST-&-WASHER-(STAR)



MULTIPLE USES CONE HOLDERS FOR 364, 3C1 MODELS



117278 HANDLE INNER,
117279 HANDLE OUTER



117287 SOCKET-GUIDE-
WITH-CATCH-CPL



130561 DROP WIRE



132440, 131547 &
140209 SUPPORT PIECE



133125 BEARING-
COVER



140216 LOCKER-PIECE-
ASSY



140331 BRAKE-LEVER-
ASSY.



140625 CAM-ASSY



141003-P-T-R-ASSY.-&
P-T-R-CERAMIC-TYPE



146466-CRADLE-WING
& ADOPTORS



152098-&-154306-
STEM-WITH-YARN-
HOLDING-ASSY.-&-
CAPSULE



156520 BRAKE LEVER,
156231 SPACER